

KASSU JOINT EXAMINATIONS 2024

KENYA CERTIFICATE OF SECONDARY EDUCATION

CHEMISTRY

(PRACTICAL)

2¹/₄ HOURS

233/3-

-Paper 3

NAME.....ADM. NO.....CLASS.....

INDEX NUMBER..... DATE.....SIGNATURE.....

INSTRUCTIONS TO CANDIDATES:

- Write your name, admission number, index number and class in the spaces provided above.
- Indicate the date of exam and sign off in the spaces provided above.
- Answer all the questions in the spaces provided below each question.
- KNEC Mathematical tables and silent electronic calculators may be used.
- All working must be clearly shown where necessary.
- Candidate should take the first 15 minutes to go through the instructions.

FOR EXAMINER'S USE ONLY

QUESTIONS	MAXIMUM SCORE	CANDIDATE'S SCORE
1	22	
2(a)	10	
(b)	8	

Grand Total	40	
-------------	----	--

1. You are provided with
- **Solid A**
 - **2.0M** hydrochloric acid solution **B**
 - **0.1M** Sodium hydroxide solution **D**

You are required to determine the enthalpy change ΔH . for the reaction between solid **A** and one mole of hydrochloric acid.


Procedure 1

Using a burette, place 20.0cm³ of 2.0M hydrochloric acid, solution **B** in a 100ml beaker. Measure the temperature of the solution after every half-minute and record the values in **table 1**. At exactly **2 minutes**, add all of solid **A** to the acid. Stir the mixture gently with thermometer. Measure the temperature of the mixture after every **half-minute** and record the values in **table 1**. **Retain the mixture for use in Procedure II**.

Table 1 **(5marks)**

Time (min)	0	1/2	1	1 1/2	2	2 1/2	3	3 1/2	4	4 1/2	5
Temperature (c)					X						

(a) Plot a graph of temperature (y-axis) against time. **(3marks)**



(b) Using the graph determine the change in temperature, ΔT

(1mark)

.....

(c) Calculate the heat change for the reaction. (Assume that the specific heat capacity of the mixture of the mixture is $4.2\text{Jg}^{-1}\text{K}^{-1}$ and the density of the mixture is 1g/cm^3). (2marks)

.....

.....

.....

.....

.....

Procedure II

Rinse the burette thoroughly and fill it with sodium hydroxide solution **D**. Transfer all the contents of the 100 ml beaker used in **procedure 1** into a 250ml volumetric flask. Add distilled water to make up to the mark. Label this **solution C**. Using pipette and a pipette filler, place **25.0 cm³** of solution C into a 250ml conical flask. Add two or three drops of phenolphthalein indicator and titrate against sodium hydroxide until a permanent pink colour just appears. Record your results in table. Repeat titration **two more times** and complete table 2.

Table 2

(4marks).

	I	II	III
Final burette reading (cm ³)			
Initial burette reading (cm ³)			
Average volume of D used (cm ³)			

Calculate the:

(d) Average volume of sodium hydroxide **solution D** used.

(1mark)

.....

.....

.....

.....

(e) The number of mole of:

i. Sodium hydroxide **solution D used.** (1mark)

.....

.....

.....

ii. Hydrochloric acid in **25 cm³** of solution **C.** (1mark)

.....

.....

.....

iii. Hydrochloric acid in **250 cm³** of solution **C.** (1mark)

.....

.....

.....

iv. Hydrochloric acid in **20.0 cm³** of solution **B.** (1mark)

.....

.....

.....

v. Hydrochloric acid that reacted with solid **A.** (1mark)

.....

.....

.....

(f) Calculate the **Molar enthalpy** of reaction between solid **A** and one mole of hydrochloric acid.

(2marks)

.....

.....

.....

.....

2. (I) You are provided with **solid Q**. Carry out the tests below and record your observations and inferences in the spaces provided.

Observation	Inference

Observation	Inference

Observation	Inference

Observation	Inference
-------------	-----------

(1/2mark)	(1mark)
------------------	----------------

(iv) To the third portion, add dilute nitric (V) acid followed by barium nitrate solution..

Observation	Inference
(1mark)	¹/₂mark)

(v) To the forth portion, add few drops of sodium hydroxide until in excess.

Observation	Inference
(1mark)	(1 mark)

(vi) To the firth portion, add few drops of aqueous ammonia until in excess.

Observation	Inference
(1 mark)	(1 mark)

(a) Place a spatula-end full of **solid R** in dry boiling tube and add about 10 cm³ of distilled water. Shake thoroughly and divide the solution into **five** portions.

(b) (i) Test the first portion with the universal indicator solution provided.

(ii) to the second portion, add a few drops of acidified potassium manganate (VII) solution.

(iii) To the third portion, add few drops of bromine water.

Get more resources from: [Enovate KCSE Revision App](#)

- | Observation | Inference |
|-------------|-----------|
| | |

- | Observation | Inference |
|-------------|-----------|
| | |

8
highschool.co.ke